

BLADE DRIVE ASSEMBLIES			BLADE DRIVE PIECE PARTS		
VRM PN	WMC PN	DESCRIPTION	VRM PN	WMC PN	DESCRIPTION
26-336-GHS	7600-4	36GHS HD Blade Drive	10035	VR011	1-1/4 Retainer Ring
26-336-SD	7600-3	36SD HD Blade Drive	10039	VR012	1/4 x 3/4 Woodruff Key
26-342-GHS	7600-7	42 GHS HD Blade Drive	11625	VR007	5/16-18x3/4 Screw
26-342-GHS-E	7600-5	42E HD Blade Drive	11626	VR008	5/16-18x1 Screw
26-342-SD	7600-6	42SD/DML HD Blade Drive	11629	VR017	.513 x 1.245 x .12 HT Washer
26-348-GHS	7600-10	48GHS HD Blade Drive	11672	VR018	Bearing Cone
26-348-GHS-E	7600-8	48E HD Blade Drive	11673	VR019	Bearing Cup
26-348-GHS-E2	7600-60	48EO HD Blade Drive	11676	VR010	Expansion Plug
26-348-SD	7600-9	48SD HD Blade Drive	11678	VR001	Seal Protector
26-456-1-SD	7600-2	56SD HD Blade Drive	11679	VR002	2-1/4 Retainer Ring
26-574-1-SD	7600-1	74SD HD Blade Drive	11680-05	VR023	Shim M26, .005 Alum. STD
BLADE DRIVE SINGLE BOX AND TUBE ASSEMBLIES			11681-05	VR024	Shim M26, .005 Aluminum
VRM PN	WMC PN	DESCRIPTION	11682	VR020	Thrust Washer
W010K	VR100	Gearbox Assembly 48GHS/E/EO	11684	VR021	Ball Bearing
W011K	VR101	Right Gearbox Assembly 36/42GHS	11689	VR006	2-3/4 Retainer Ring
W012K	VR102	Gearbox Assembly 36/42/48GHS/SD	11690	VR005	Access Cover
W013K	VR103	Gearbox Assembly 36/42SD	11699	VR003	Seal (Viton)
W014AK	VR104	Gearbox Assembly 56/74SD	11701	VR022	1/2-20 UNF Lock nut
W014K	VR105	Gearbox Assembly 56-1/74-1SD	20880	---	Blade Drive Shim
W015AK	VR106	Gearbox Case Assembly 56/74SD	35547	VR026	Gear, Spiral RH/29 Tooth
W015K	VR107	Gearbox Assembly 56-1/74-1SD	35548	VR027	Gear, Spiral RH/24 Tooth
W016AK	---	Gearbox Assembly 74SD	35549	VR028	Gear, Spiral LH/24 Tooth
W016K	VR108	Gearbox Assembly 74-1SD	35559	VR029	Gear, Spiral LH/29 Tooth
W017K	VR109	Gearbox Assembly 42/48E/48/EO	35560	VR030	Gear, Spiral RH/24 Tooth
W018K	VR110	42E Gearbox Assembly	35561	VR031	Gear, Spiral LH/24 Tooth
W019K	VR111	Gearbox 36&42GHS/E/SD&48SD	35564	VR032	End Cap W/Flat
W020AK	VR112	Gearbox Assembly 56/74SD	35574	VR033	Gear, Spiral RH/21 Tooth
W020K	VR113	Gearbox Assembly 56-1/74-1SD	35575	VR034	Gear, Spiral LH/23 Tooth
W021AK	---	Gearbox Assembly 74SD	42430	VR035	Connecting Shaft (11-11/16)
W021K	VR114	Gearbox Assembly 74-1SD	42434	VR036	Connecting Tube (6-3/8)
W022AK	VR115	Gearbox Assembly 56SD	42435	VR037	Connecting Tube (9")
W022K	VR116	Gearbox Assembly 56-1SD	42437	VR038	Connecting Tube (9-1/16)
W023K	VR117	Gearbox Assembly 48GHS	42439	VR039	Connecting Tube (14-3/16)
W024K	VR118	48E/EO Gearbox Assembly	42440	VR040	Connecting Tube (8-5/16)
W030-K	VR200	Left Tube Assembly 48GHS	42441	VR041	Connecting Tube (2")
W031-K	VR201	Tube Assembly 48GHS	42442	VR042	Connecting Tube (3-3/8)
W032-K	VR202	Tube Assembly 42E/48SD	42443	VR043	Connecting Tube (4-1/16)
W033-K	VR203	Tube Assembly L-36GHS/SD R-48SD	42444	VR044	Connecting Tube (11-5/16)
W034A-K	VR204	Tube Assembly 56/74SD	42445	VR045	Connecting Shaft (20")
W034-K	VR205	Tube Assembly L-56-1SD L/R-74-1SD	42446	VR046	Connecting Shaft (11")
W035-K	VR206	Left Tube Assembly 42GHS/SD	42447	VR047	Connecting Shaft (4-11/16)
W036A-K	VR207	Tube Assembly 56/74SD	42448	VR048	Connecting Shaft (5-13/16)
W036-K	VR208	Tube Assembly LC-56-1SD RC-74-1SD	42450	VR049	Connecting Shaft (6-3/4)
W037-K	VR209	Tube Assembly 36SD	42451	VR050	Connecting Shaft (9-13/16)
W038-K	VR210	Tube Assembly 36GHS	42452	VR051	Connecting Shaft (14")
W039-K	VR211	42E Tube Assembly	42453	VR052	Connecting Shaft (12-3/16)
W040-K	VR212	Tube Assembly 42SD	42460	VR053	Output Shaft
W041-K	VR213	Tube Assembly 42GHS	42461	VR054	Input Shaft
W042-K	VR214	Tube Assembly 48E	42462	VR055	Output Shaft/Euro
W043-K	VR215	Tube Assembly 48E	42483	VR056	Connecting Tube (10")
W044A-K	VR216	Tube Assembly 56/74SD	42484	VR057	Connecting Shaft (12-11/16)
W044-K	VR217	Tube Assembly R-56-1SD LC-74-1SD	56246	VR058	Gearbox Housing/Center
W045K	VR119	Gearbox Assembly 48SD	56247	VR059	Gearbox Housing/RH
W046-K	VR218	48EO Tube Assembly	56248	VR060	Gearbox Housing/LH
W047-K	VR219	48EO Tube Assembly	56258	VR061	Gearbox Housing/RH
			56267	VR066	Gearbox Housing/End/LH
			56268	VR062	Gearbox Housing/Center/LH
			56270	VR063	Gearbox Housing/End/RH
			56280	VR064	Gearbox Housing/End/RH
			56281	VR065	Gearbox Housing/End/RH
			64018	VR009	O-Ring Plug
			80185	VR004	O-Ring/HD (Viton)

BLADE DRIVE ASSEMBLIES			BLADE DRIVE PIECE PARTS		
VRM PN	WMC PN	DESCRIPTION	VRM PN	WMC PN	DESCRIPTION
26-574-1-SD	7600-1	74SD HD Blade Drive	11678	VR001	Seal Protector
26-348-GHS	7600-10	48GHS HD Blade Drive	11679	VR002	2-1/4 Retainer Ring
26-456-1-SD	7600-2	56SD HD Blade Drive	11699	VR003	Seal (Viton)
26-336-SD	7600-3	36SD HD Blade Drive	80185	VR004	O-Ring/HD (Viton)
26-336-GHS	7600-4	36GHS HD Blade Drive	11690	VR005	Access Cover
26-342-GHS-E	7600-5	42E HD Blade Drive	11689	VR006	2-3/4 Retainer Ring
26-342-SD	7600-6	42SD/DML HD Blade Drive	11625	VR007	5/16-18x3/4 Screw
26-348-GHS-E2	7600-60	48EO HD Blade Drive	11626	VR008	5/16-18x1 Screw
26-342-GHS	7600-7	42 GHS HD Blade Drive	64018	VR009	O-Ring Plug
26-348-GHS-E	7600-8	48E HD Blade Drive	11676	VR010	Expansion Plug
26-348-SD	7600-9	48SD HD Blade Drive	10035	VR011	1-1/4 Retainer Ring
BLADE DRIVE SINGLE BOX AND TUBE ASSEMBLIES			10039	VR012	1/4 x 3/4 Woodruff Key
VRM PN	WMC PN	DESCRIPTION	11629	VR017	.513 x 1.245 x .12 HT Washer
W010K	VR100	Gearbox Assembly 48GHS/E/EO	11672	VR018	Bearing Cone
W011K	VR101	Right Gearbox Assembly 36/42GHS	11673	VR019	Bearing Cup
W012K	VR102	Gearbox Assembly 36/42/48GHS/SD	11682	VR020	Thrust Washer
W013K	VR103	Gearbox Assembly 36/42SD	11684	VR021	Ball Bearing
W014AK	VR104	Gearbox Assembly 56/74SD	11701	VR022	1/2-20 UNF Lock nut
W014K	VR105	Gearbox Assembly 56-1/74-1SD	11680-05	VR023	Shim M26, .005 Alum. STD
W015AK	VR106	Gearbox Case Assembly 56/74SD	11681-05	VR024	Shim M26, .005 Aluminum
W015K	VR107	Gearbox Assembly 56-1/74-1SD	35547	VR026	Gear, Spiral RH/29 Tooth
W016K	VR108	Gearbox Assembly 74-1SD	35548	VR027	Gear, Spiral RH/24 Tooth
W017K	VR109	Gearbox Assembly 42/48E/48/EO	35549	VR028	Gear, Spiral LH/24 Tooth
W018K	VR110	42E Gearbox Assembly	35559	VR029	Gear, Spiral LH/29 Tooth
W019K	VR111	Gearbox 36&42GHS/E/SD&48SD	35560	VR030	Gear, Spiral RH/24 Tooth
W020AK	VR112	Gearbox Assembly 56/74SD	35561	VR031	Gear, Spiral LH/24 Tooth
W020K	VR113	Gearbox Assembly 56-1/74-1SD	35564	VR032	End Cap W/Flat
W021K	VR114	Gearbox Assembly 74-1SD	35574	VR033	Gear, Spiral RH/21 Tooth
W022AK	VR115	Gearbox Assembly 56SD	35575	VR034	Gear, Spiral LH/23 Tooth
W022K	VR116	Gearbox Assembly 56-1SD	42430	VR035	Connecting Shaft (11-11/16)
W023K	VR117	Gearbox Assembly 48GHS	42434	VR036	Connecting Tube (6-3/8)
W024K	VR118	48E/EO Gearbox Assembly	42435	VR037	Connecting Tube (9")
W045K	VR119	Gearbox Assembly 48SD	42437	VR038	Connecting Tube (9-1/16)
W030-K	VR200	Left Tube Assembly 48GHS	42439	VR039	Connecting Tube (14-3/16)
W031-K	VR201	Tube Assembly 48GHS	42440	VR040	Connecting Tube (8-5/16)
W032-K	VR202	Tube Assembly 42E/48SD	42441	VR041	Connecting Tube (2")
W033-K	VR203	Tube Assembly L-36GHS/SD R-48SD	42442	VR042	Connecting Tube (3-3/8)
W034A-K	VR204	Tube Assembly 56/74SD	42443	VR043	Connecting Tube (4-1/16)
W034-K	VR205	Tube Assembly L-56-1SD L/R-74-1SD	42444	VR044	Connecting Tube (11-5/16)
W035-K	VR206	Left Tube Assembly 42GHS/SD	42445	VR045	Connecting Shaft (20")
W036A-K	VR207	Tube Assembly 56/74SD	42446	VR046	Connecting Shaft (11")
W036-K	VR208	Tube Assembly LC-56-1SD RC-74-1SD	42447	VR047	Connecting Shaft (4-11/16)
W037-K	VR209	Tube Assembly 36SD	42448	VR048	Connecting Shaft (5-13/16)
W038-K	VR210	Tube Assembly 36GHS	42450	VR049	Connecting Shaft (6-3/4)
W039-K	VR211	42E Tube Assembly	42451	VR050	Connecting Shaft (9-13/16)
W040-K	VR212	Tube Assembly 42SD	42452	VR051	Connecting Shaft (14")
W041-K	VR213	Tube Assembly 42GHS	42453	VR052	Connecting Shaft (12-3/16)
W042-K	VR214	Tube Assembly 48E	42460	VR053	Output Shaft
W043-K	VR215	Tube Assembly 48E	42461	VR054	Input Shaft
W044A-K	VR216	Tube Assembly 56/74SD	42462	VR055	Output Shaft/Euro
W044-K	VR217	Tube Assembly R-56-1SD LC-74-1SD	42483	VR056	Connecting Tube (10")
W046-K	VR218	48EO Tube Assembly	42484	VR057	Connecting Shaft (12-11/16)
W047-K	VR219	48EO Tube Assembly	56246	VR058	Gearbox Housing/Center
W016AK	---	Gearbox Assembly 74SD	56247	VR059	Gearbox Housing/RH
W021AK	---	Gearbox Assembly 74SD	56248	VR060	Gearbox Housing/LH
			56258	VR061	Gearbox Housing/RH
			56268	VR062	Gearbox Housing/Center/LH
			56270	VR063	Gearbox Housing/End/RH
			56280	VR064	Gearbox Housing/End/RH
			56281	VR065	Gearbox Housing/End/RH
			56267	VR066	Gearbox Housing/End/LH
			20880	---	Blade Drive Shim